



**CAUTION:** Relief Valve (Item # 4) must be set to 10,500-11,000 PSI.

**TO PROTECT YOUR WARRANTY, USE ONLY ENERPAC HYDRAULIC OIL.**

<b>REPAIR PARTS LIST</b>			
<b>Item</b>	<b>Part Number</b>	<b>Qty</b>	<b>Description</b>
3	★ CH875041	1	U Cup
4	G586900SR-10750	1	Safety Valve Assembly
5	★ B1441513	1	GT Ring Assembly
6	★ B1431514	1	GT Ring
7	DA12403900	2	Female Coupler
8	★ M456044	1	Wiper Ring
9	★ S3037	1	Gasket
10	Y931044	1	Stop Ring
11	M260030	1	Cylinder
12	★ CM441028	1	Plug Screw
13	★ DD7621565	1	Backup, POM 7.50 x 6.50 x .115
14	M3040	1	Plunger
15	B1015120	2	Hex Nut
16	CM578242	2	Hex Bolt
17	CB804045	1	Saddle
18	B1069028	2	Screw
★ Included in and available only as a part of Repair Kit RR2006K1.			



www.enerpac.com