




Figure 1, Pump Assembly

Repair Parts List for Figure 1

Item	Part Number	Qty.	Description	Item	Part Number	Qty.	Description
1	Pump unit Assembly (see Fig. 2) Not sold separately—order complete pump.			7	DA11986020	1	End Cap
2	★B1135517	1	Square Ring Seal	8	★DA10722108	1	Washer
3	★DA3729900	1	Filter Assembly	9	★B1009503	1	O-ring
4	DC1115025	1	Reservoir	10	CL341055	1	Acorn Nut
5	DA9159107	1	Tie Rod	11	CT2588900	1	Filter Plug Assembly
6	★B1246503	1	O-ring	12	DA9161070	1	Handle
				13	CL343550	1	Handle Grip

★ Items included in Repair Kit P392ALK.




Figure 2, Pumping Unit Assembly (cont. on page 2)

Repair Parts List for Figure 2			
Item	Part Number	Qty.	Description
1	Not available as service part		Pump Base
2	CN815006	2	Pipe Plug
3	★ DA1176210	2	Conical Spring
4	★ B1009016	2	5/16" Ball
5	★ B1006016	3	7/32" Ball
6	DA6301900	1	Release Valve Spindle
7	★ CU921028	1	Truss Head Machine Screw
8	★ B1007503	1	O-ring
9	CR333040SR	1	Plunger Assembly
10	DA8802900SR	1	High Pressure Relief Valve Assy
12	★ B1011803(+)	1	O-ring
13	★ B1011564(+)	1	Back-Up Washer
14	★ B1119803	1	O-ring
15	★ CR188564	1	Back-up Washer
17	DA5493900SR	1	Low Pressure Relief Assy.
19	CL918900	1	Beam/Handle
20	DC106061SR(+)	1	Beam Pin
21	★ DA1177349(+)	2	Retaining Ring
22	CR214061SR	1	Beam Pin
23	CM927061	1	Locking Pin
24	★ Y267110	1	Spring
25	★ CM928044	1	Push-on Ring
50	★ DA3702020	2	Spring Cap
52	★ DA4896446(+)	1	Sleeve Protector
53	★ DC7363225	1	Wiper

★ Items included in and available only as part of Repair Kit P392ALK.
 (+) Items that are part of the plunger assembly (Item 9). Item 52 is not shown separately on the parts drawing.




Figure 2, Pumping Unit Assembly

◆ internet: www.enerpac.com

◆ e-mail: info@enerpac.com

Enerpac Worldwide Locations

Australia and New Zealand
 Actuant Australia Ltd.
 P.O. Box 6867, Werrihill Park, NSW 1851
 Block V Unit 3, Regents Park Estate
 391 Park Road, Regents Park NSW 2143
 Australia
 T +61 287 177 200
 F +61 297 438 648

Brazil
 Power Packer do Brasil Ltda.
 Rua Luiz Lawrie Reid, 548
 09830-760 - Diadema (SP) - Brazil
 T +55 11 5687 2211
 Toll Free: 0800 891 5770

China (Taipei)
 Actuant (China) Industries Co. Ltd.
 No. 6 Nanjing East Road,
 Taicang Economic Dep Zone
 Jiangsu, China
 T +86 0512 5328 7500
 F +86 0512 5335 9690
 Toll Free: +86 400 885 0369

France, Switzerland, North Africa and French speaking African countries
 ENERPAC
 Une division d'Actuant France S.A.S.
 Zone OrlyTech Bâtiment 516
 1 allée du commandant Mouchotte
 CS 40351
 91550 Paray-Vielles-Postes
 France
 T +33 1 60 13 68 68
 F +33 1 69 20 37 50

Germany and Austria
 Actuant GmbH
 P.O. Box 300113
 D-40401 Düsseldorf
 Willstätterstrasse 13
 D-40649 Düsseldorf, Germany
 T +49 211 471 490
 F +49 211 471 49 28

India
 Actuant India Private Limited
 No. 10, Ballary Road, Sadashivanagar,
 Bangalore, Karnataka 560 080
 India
 T +91 80 3928 9000

Italy
 ENERPAC S.p.A.
 Via Carova 4
 20094 Corsico (Milano)
 T +39 02 4861 111
 F +39 02 4860 1288

Japan
 Enerpac Co., Ltd.
 Besshocho 85-7
 Kita-ku, Saitama-shi 331-0821, Japan
 T +81 48 662 4911
 F +81 48 662 4955

Middle East, Egypt and Libya
 ENERPAC Middle East FZE
 Plot M00737m/1242nd Street
 Jebel Ali Free Zone North
 P.O. Box 18004, Dubai
 United Arab Emirates
 T +971 04 8872686
 F +971 04 8872687

Norway
 Sales Office Norway
 Unit 324, Nydalsveien 28, 0484 Oslo
 P.O. Box 4614, Nydalen 0422 Oslo
 Norway
 Tel: +47 91 578 300

Russia
 Rep. office Enerpac
 Russian Federation
 Admiral Makarova Street 8
 125212 Moscow, Russia
 T +7 495 98090 91
 F +7 495 98090 92

Southeast Asia, Hong Kong and Taiwan
 Actuant Asia Pte Ltd.
 83 Joo Koon Circle
 Singapore 629109
 T +65 68 63 0611
 F +65 64 84 5669
 Toll Free: +1800 363 7722

South Korea
 Actuant Korea Ltd.
 35a 717, Shilva Industrial Complex
 Jungnang-Dong, Shihung-Shi,
 Kyunggi-Do
 Republic of Korea 429-450
 T +82 31 434 4506
 F +82 31 434 4507

Spain and Portugal
 ENERPAC SPAIN S.L.
 Avda. Valdeaparra N° 2° 3° - L8
 28108 Alcobendas (Madrid), Spain
 T +34 91 894 86 06
 F +34 91 894 86 11

Sweden, Denmark, Finland and Iceland
 Enerpac Scandinavia AB
 Kopparfundsvägen 14,
 721 30 Västerås
 Sweden
 T +46 (0) 771 41 50 00

The Netherlands, Belgium, Luxembourg, Central and Eastern Europe, Baltic States, Greece, Turkey and CIS countries
 ENERPAC B.V.
 Galvanisstraat 115, 6716 AE Ede
 P.O. Box 8097, 6710 AB Ede
 The Netherlands
 T +31 318 535 911
 F +31 318 535 848

Enerpac Heavy Lifting Technology B.V.
 Spindelstraat 15, 7554 TS Hengelo
 P.O. Box 421, 7550 AK Hengelo
 The Netherlands
 T +31 74 242 20 45
 F +31 74 243 03 38

South Africa and other English speaking African countries
 Enerpac Africa Pty Ltd.
 No. 5 Buthina Avenue
 Cambridge Office Park
 Block E, Techno Park
 Centurion 0157
 Republic of South Africa
 T: +27 12 940 0656

United Kingdom and Ireland
 ENERPAC UK Ltd.
 5 Coopers Field
 Morpeth, Northumberland
 NE61 6JR, England
 T +44 1670 5010 00

USA, Latin America and Caribbean
 ENERPAC World Headquarters +27 12
 P.O. Box 3241
 Milwaukee WI 53201-3241 USA
 N86 W12500 Westbrook Crossing
 Menomonee Falls, Wisconsin 53051
 T +1 262 283 1600
 F +1 262 283 7036
 User inquiries:
 T +1 800 433 2766
 Distributor inquiries/orders:
 T +1 800 558 0530
 F +1 800 628 0490

All Enerpac products are guaranteed against defects in workmanship and materials for as long as you own them.

For the location of your nearest authorized Enerpac Service Center, visit us at www.enerpac.com

040717