



NOTE: Safety valve (item 18) to be preset to 11,000 - 11,500 PSI [760 - 795 bar]

(S) Indicates staked threads. Stake mark must be removed prior to disassembly. Failure to do so may result in damage to parts. Some cylinder stop rings are assembled with Loctite on threads. Stake threads when reassembling.

TO PROTECT YOUR WARRANTY, USE ONLY ENERPAC HYDRAULIC OIL.

Parts List						
Item	RR-20018	RR-20024	RR-20036	RR-20048	Qty.	Description
1	B1069028	B1069028	B1069028	B1069028	2	Capscrew
2	CB804045	CB804045	CB804045	CB804045	1	Saddle
3	CD411	CD411	CD411	CD411	2	Dust Cap
4	M204044	M204044	M204044	M204044	1	Retaining Ring
5	★ M456044	★ M456044	★ M456044	★ M456044	1	Wiper Ring
6	★ B1431514	★ B1431514	★ B1431514	★ B1431514	1	G-T Ring
7	M238044	M238044	M238044	M238044	1	Plunger Guide
8	CA13604018	CA13604024	CA13604036	CA13604048	1	Plunger
9	N/A	N/A	N/A	N/A	1	Base
10	★ B1054503	★ B1054503	★ B1054503	★ B1054503	1	O-Ring
11	★ B1441513	★ B1441513	★ B1441513	★ B1441513	3	G-T Ring Ass'y
12	★ B1073562	★ B1073562	★ B1073562	★ B1073562	1	Back-Up Washer
13	M241051	M241051	M241051	M241051	1	Piston
14	★ CH875041	★ CH875041	★ CH875041	★ CH875041	1	U-Cup
15	CR400	CR400	CR400	CR400	2	Half Coupler
16	M247044	M247044	M247044	M247044	1	Stop Ring
17	CA132044	CA132044	CA132044	CA132044	1	Base Retaining Ring
18	CJ160900W	CJ160900W	CJ160900W	CJ160900W	1	Relief Valve
19	★ DD7261565	★ DD7261565	★ DD7261565	★ DD7261565	1	Backup, POM
20	CM441028	CM441028	CM441028	CM441028	1	Screw, Plug
21	DA7323242	DA7323242	DA7323242	DA7323242	2	Eye Bolt
22	DA7324108	DA7324108	DA7324108	DA7324108	2	Shim Washer

★ Indicates items included in Repair Kit RR20048K. N/A = Not Available